

# Zebra ZD410/ZD411 Label Printer configuration

This document provides detailed instructions for changing the label size and orientation of the Zebra\* ZD410 and the Zebra\* ZD411 Label Printer installed on Cornerstone\* Software systems.

## Where to perform these steps


**If the printer is connected with a USB cable:** All operations will be performed on the station to which the printer is physically connected.

**If the printer is connected with an external or internal print server using an Ethernet cable:** All operations will be performed on the server computer.


## Required label size and orientation

It is important to use the ZD410/ZD411 ZPL (203 dpi) version of the ZDesigner Printer Driver. If any other version is used, the labels will not print correctly.

## To specify settings for prescription labels:

1. Click Windows , type run, and press Enter.
2. Type **control printers** and click **OK**.
3. Open the Zebra printer preferences window as follows:
  - a. Right-click the Zebra printer name.
  - b. Click **Printer Properties**.
  - c. On the General tab, click **Preferences**.
4. Set the following on the **Page Setup** tab:
  - a. Select **90° - Landscape** from the **Rotation** drop-down box.
  - b. Set the **Width** to **2.0** (5.08 CM).
  - c. Set the **Height** to **3.50** (8.89 CM).
  - d. Click **OK**.
5. Click the **Advanced** tab and then click **Printing Defaults**.
6. Repeat **step 4**.
7. Click **OK**.

## To specify settings for test-tube labels:

1. Click **Windows** , type **run**, and press **Enter**.
2. Type **Control Printers**.
3. Open the Zebra printer preferences window as follows:
  - a. Right-click the Zebra printer name.
  - b. Click **Printer Properties**.
  - c. On the General tab, click **Preferences**.
4. Set the following settings on the **Page Setup** tab:
  - a. Select **0° - Portrait** from the **Rotation** drop-down box.
  - b. Set the **Width** to **1.25** (3.17 CM).
  - c. Set the **Height** to **.84** (2.13 CM).
5. Click the **Print Options** tab.
  - a. For the **ZD410**, set the **Top** offset to **0.06**.  
For the **ZD411**, set the **Top** offset to **0.04**.
  - b. Click **OK**.
6. Click the **Advanced** tab and then click **Printing Defaults**.
7. Repeat **step 4** and **step 5**.
8. Click **OK**.

For assistance, call Cornerstone Support at 1-800-695-2877.



© 2023 IDEXX Laboratories, Inc. • All rights reserved. • 06-66508-01

\* Cornerstone is a trademark or registered trademark of IDEXX Laboratories, Inc. or its affiliates in the United States and/or other countries. All other product and company names and logos are trademarks of their respective holders.